Notes -

- 1. The device is a high-temperature product, it is normal that the housing becomes moderately heated during use. 2.If the housing get too hot to touch by hand during use, please trun of to cool down. 3.Continuous use may trigger over-heat projection system
- to force the device stop working, until the temperature down to safety range.

Kind Reminder -

- To get better understanding and using of the device, please read this manual carefully. 1.This product is not intend for use by persons under
- I have been a set of the set of t and asthma.
- 2.Battery built-in the device, please do not expose the device to high temperature or high humidity environment. 3.Keep the device away from water.

4. Turn off the device when not in use.

Warranty __

30 days from the date of purchase against manufacturer defects. Does not apply improper manual operation. Used consumables are not covered by the warranty



🚯 🕲 CE 🅢 🛎 🛟





How to use -Open the lid (magnetic) and put the wax in the atomizer cup before turning on the device. Turn On/Off:

- 1. Press the power button 5 times within 2S to turn on/off.
- Press the power button 5 times within 25 to turn on/off.
 Preheat After the device is turned on, it will automatically enter the preheating state for 8S (The indicator light will alternately flash green, blue, and white a total of 13 times).
 After preheating, the device will default to the Mode 1 (Low): Green voltage setting.

- (Low): Green voltage setting. Change Voltage 1. Press the power button 2 times within 0.85 to change the voltage. 3 Voltage Modes Mode 1 (Low): Green 3.5V Mode 2 (Mid): Blue 3.7V Mode 3 (High): White 3.9V Manual Mode 1. Press and hold the power button to start vaping. (Continue to hold the power button for up to 10s. After 105 the device will stop heating. The light will flash 3 times, and it will enter standby) 2. Turn off: Press the power button 5 times within 25 to turn off the device (The indicator light will flash white 3 times). Device will automatically turn off if there is no operation for 5 minutes.
- Caution: It can damage the atomizer coil or the device if it is used without wax in the atomizer coil.

Alarm Indications

- Anarm male at the indicator light flashes red 5 times. Please charge the device.
 2. High-temperature Protection: The indicator light flashes purple 5 times. Allow the device to cool down before attempting to use it again.
 3. Output Short-Circuit: The indicator light flashes yellow 8 times, please change the atomizer.
 4. Open Circuit: The indicator light flashes yellow 5 times, please change the atomizer.
- Charging —

1.When charging, the indicator light will flash red. 2.When fully charged, the indicator light changes to green. Product Feature —

Features: 1.Replaceable atomizer, diverse choices. Linepiaceable atomizer, diverse choices. 2.Three temperature modes to meet different needs 3.Magnetic mouthpiece, easier to use 4.Built-in dab tool 5.Battery: 950MAH 6.Charging current (battery side) 250mA 7.Charging voltage (input) USB 5V